

SOLAR LED Ground Light

USER INSTRUCTIONS

- The instructions apply to each light. Follow the instructions.

Product contents

1. solar light (upside down, its backside faces up)
2. split ground stake (short)
3. sharp end ground stake (long)

Assembly and Use




button

1



2



3

1. Push the button once to activate the light.
2. Align the 2 pins of the split ground stake to the 2 holes on the back of the solar light and then push the split ground stake firmly onto the solar light.
3. Align the 2 pins of the sharp end ground stake to the 2 remaining holes on the back of the solar light. Push the sharp end ground stake through the slot of the split ground stake onto the solar light.
4. Flip the solar light so that its solar panel side faces up.
5. In your garden, find a soft ground where the solar panel can receive direct sunlight.
6. Insert the combined ground stakes into the soil to fix the light.
7. The solar light turns on at dusk and off at dawn automatically.

Note: if you will not use the product for a long period of time, pull it up, push the button again to deactivate it, disassemble it and then store it.

Specification

Material: PP, PC, stainless steel

Size: 12 (dia.) x 13 (h) cm

LED: 8 x white

Battery: 1 x AAA Ni-MH 600mAh

